

## **NCR 7875 – Advanced Configuration**



After the setup has been completed but the barcodes are not scanning, or the scale is not correctly weighing items please follow the steps below.



- **Disable Soft Defaults**
  - **Setting Factory Defaults**
- **Check Communications Method**
- **Set Communication method to RS-232**



## Disable Soft Defaults

Scanning the Default tag should reset the device to factory defaults, but in some cases it may not.

To set the system to use the default tags correctly please scan the barcodes in order below:

After making any of the following changes to the scale you will need to contact Weights and Measures to make sure the scale are certified and weighing items properly.



1.	<p data-bbox="667 604 737 632">Reset</p> 
2.	<p data-bbox="667 1033 886 1060">Programming Mode</p> 
3.	<p data-bbox="667 1461 737 1488">Hex 3</p> 

4.	<p data-bbox="667 233 735 260">Hex 4</p> 
5.	<p data-bbox="667 667 735 695">Hex 0</p> 
6.	<p data-bbox="667 1108 849 1136">Save and Reset</p> 

After disabling the soft reset we will then want to try to reset the system to factory defaults see: **Setting Factory Defaults.**

## Setting Factory Defaults

After making any of the following changes to the scale you will need to contact Weights and Measures to make sure the scale are certified and weighing items properly.



1.	<p data-bbox="667 422 737 447">Reset</p> 
2.	<p data-bbox="667 854 751 879">Default</p> 
3.	<p data-bbox="667 1295 849 1320">Save and Reset</p> 

After setting factory defaults please open CRE and try to scan a barcode.

## Check Communications Method

To use the NCR 7875 scanner/scale the device must be communicating via RS-232.


To check the communication method that the NCR 7875 is using please scan the barcodes in order below:

1.	<p data-bbox="667 491 737 516">Reset</p> 
2.	<p data-bbox="667 919 854 945">Diagnostic Mode</p> 
3.	<p data-bbox="667 1348 737 1373">Hex 3</p> 

The scanner scale will then indicate which communication method it is using by one of the following two methods:

The device will beep 6 times stating that it is using RS-232 as the connection method. If it beeps any other number of times then we will need to **Set the Communication Method to RS-232.**


The Device will speak "R-S-2-3-2".




4.	<p data-bbox="667 663 737 688">Reset</p> 
----	--


## Set Communication method to RS-232

After making any of the following changes to the scale you will need to contact Weights and Measures to make sure the scale are certified and weighing items properly.

To set the system to use RS-232 as the connection methods please scan the barcodes in order below:

1.	<p data-bbox="667 531 737 558">Reset</p> 
2.	<p data-bbox="667 961 886 989">Programming Mode</p> 
3.	<p data-bbox="667 1392 737 1419">Hex 1</p> 

4.	<p data-bbox="667 233 735 260">Hex 0</p> 
5.	<p data-bbox="667 667 735 695">Hex 5</p> 
6.	<p data-bbox="667 1108 716 1136">End</p> 

7.	<p data-bbox="669 237 849 264">Save and Reset</p> 
----	--

After setting the correct communication method please open CRE and try to scan a barcode.